

Table of Coordinates

Channel-number	Name	Theta	Phi
1	Fp1	-90	-72
2	Fpz	90	90
3	Fp2	90	72
4	AF7	-90	-54
5	AF3	-74	-68
6	Afz	67	90
7	AF4	74	68
8	AF8	90	54
9	F7	-90	-36
10	F5	-74	-41
11	F3	-60	-51
12	F1	-49	-68
13	Fz	45	90
14	F2	49	68
15	F4	60	51
16	F6	74	41
17	F8	90	36
18	FCz	23	90
19	FT7	-90	-18
20	FC5	-69	-21
21	FC3	-49	-29
22	FC1	-31	-46
23	FC2	31	46
24	FC4	49	29
25	FC6	69	21
26	FT8	90	18
27	T10'	113	3
28	T9'	-113	3
29	T7	-90	0
30	C5	-68	0
31	C3	-45	0
32	C1	-23	0
33	Cz	0	0
34	C2	23	0
35	C4	45	0
36	C6	68	0
37	T8	90	0
38	PO3	-74	68
39	POz	67	-90
40	PO4	74	-68
41	TP7	-90	18
42	CP5	-69	21
43	CP3	-49	29
44	CP1	-31	46
45	CPz	22	-90

46	CP2	31	-46
47	CP4	49	-29
48	CP6	69	-21
49	TP8	90	-18

Channel-number	Name	Theta	Phi
50	O1	-90	72
51	Oz	90	-90
52	O2	90	-72
53	P7	-90	36
54	P5	-74	41
55	P3	-60	51
56	P1	-49	68
57	Pz	45	-90
58	P2	49	-68
59	P4	60	-51
60	P6	74	-41
61	P8	90	-36
62	PO8	90	-54
63	Iz	112	-90
64	PO7	-90	54
REF		-	-
GND		-	-

These values are standardized to a Theta of 90° for the plane through Fpz, T7, T8, Oz.

The signs follow this convention:

